

Bänkvåg / Bench scale
Förenklat handhavande / Daily use

LEM7



www.liden-weighing.se

DAGLIG ANVÄNDNING:

Uppstart och vägning utan tara:

1. Placera vågen på stabilt underlag och i "våg".
2. Slå på huvudströmbrytaren. Finns på höger sida under vågen.
3. Starta sedan vågen via "ON/OFF" tangent.
4. Är det information i viktdisplayen tryck "ZERO" tangent.
5. Påbörja vägning.

Vägning med tara:

6. Placera behållare på vågplattan och tryck "ZERO" tangent.
7. Påbörja vägning.
8. Ta bort tara genom att trycka på "ZERO" när vågplattan är tom.

Växla mellan vikt enheter:

9. Tryck på "UNITS" för att byta vikt enhet.
(Det finns 14 st. viktenheter man kan välja mellan.)

Avstängning av batteri-spar funktionen:

10. Håll "ZERO" intryckt när vågen startas.
A-ON visas i displayen.
11. Tryck på "ZERO" en gång.
A-OFF visas i displayen.
12. Stäng av vågen och slå på den för att spara och återgå till vägning.

Styckräkning:

13. Lägg på önskat antal för referens (10-20-50 eller 100st).
14. Tryck på "PCS" (S-10pcs visas i displayen).
15. Tryck på "UNITS" för att välja rätt antal.
16. Tryck sedan på "PCS" för att bekräfta.
17. För att återgå till vägningssläge tryck på "UNITS".

DAILY USE:

Start and weighing without tare:

1. Place the scale on a stable bench or other surface.
2. Switch on the main power switch at the bottom right of the scale.
3. Press "**ON/OFF**"
4. Press "**ZERO**" if needed to zero the scale
5. Start weighing

Weighing with tare

1. Place the container on the scale platform and press "**ZERO**"
2. Start weighing
3. End weighing with tara by pressing "**ZERO**" with an empty platform.

Change between units

- Press "**UNITS**" to change between different weighing units
(There are 14 units to choose between)

Turn off battery save mode

1. Press "**ZERO**" when starting the scale
A-ON is displayed
2. Press "**ZERO**" again
A-ON is displayed
3. Turn off the scale and start it again. The scale is ready to use.

Counting

1. Place a sample on the scale platform (10-20-50 or 100 units).
2. Press "**PCS**". (S-10pcs is displayed).
3. Press "**UNITS**" to decide the correct number of samples.
4. Press "**PCS**" to confirm.
5. To exit counting mode: press "**UNITS**".